

## Watt Module



### BOX CONTENTS e-sylife

- Watt Module (78 x 54 x 27 mm / 70g) with battery
- Clamp ammeter with a power cable
- This document

### REQUIRED SYSTEM CONFIGURATION

Owning an e-sylife Kub connected to the internet.



NEED HELP ?

<http://www.e-sylife.com/en/aide-a-l'installation/>


# QUICK INSTALLATION GUIDE

The Electricity module allows you to simply identify the cost of consumption of each of your devices through the "Snapshot" to raise your family and save up to 15% on your bill. For installation in a three phase, complete the Smart Home Pack of 2 additional Watt modules, to monitor the overall consumption and phase of your home. This module also tracks the production of a wind turbine or solar panels.

## Connecting the Watt Module

⇒ ***Remember to disconnect the power supply at the electricity meter before connecting the clamp ammeter. In case of doubt, call a professional.***



- Add the Watt Module to your installation by logging into your customer space, click on "My Home  " icon, then "My modules". Click "ADD MODULE" and enter the module number and the security number found on the back of the module.
- Wait a minute.
- Skip the clamp ammeter around one of the arrival cables of your power supply (the biggest red or blue wire) and close the clamp by pressing until it clicks.
- Stay close to the Kub when you remove the tab from the battery of the electricity module to put the module into service. After you can put the module at its ultimate placement.
- Connect the mini-jack on the corresponding socket of the Watt module. It could appear "not connected" (NC) during the first 2 hours.

**Your Watt Module is now ready to go.**

**For more details please read the user's guide, available in your "Customer account".**